

Intox EC/IR II - Service Shipping Check List

Action Item		Instructions	Customer Pre-Ship Actioned (Check off)	Davtech Return Actioned (Check off)
Davtech Service Request Form		Complete the Form which is available from <u>http://www.davtech.ca/index.php/resources/downloads</u> .	<input type="checkbox"/>	N/A
EC/IR II Pelican Case	Must ship in approved case.	Have ready and open. Ensure all inserts are present.	<input type="checkbox"/>	<input type="checkbox"/>
Instrument's Power Switch:		Turn off.	<input type="checkbox"/>	<input type="checkbox"/>
Instrument's Power Cable:		Remove from the hydro receptacle.	<input type="checkbox"/>	<input type="checkbox"/>
Remove:	The dry gas tank.	*****Remove***** Do not ship with instrument. Store locally.***	<input type="checkbox"/>	N/A
	Instrument's power cable.	Store in dry gas compartment.	<input type="checkbox"/>	<input type="checkbox"/>
	E-Seek and cable.	Store in Pelican case in the insert space provided.	<input type="checkbox"/>	<input type="checkbox"/>
	Printer and Cable.	Do not ship with instrument. Store locally.	<input type="checkbox"/>	<input type="checkbox"/>
	Keyboard.	Store in Pelican case in the insert space provided.	<input type="checkbox"/>	<input type="checkbox"/>
	External Heated Simulator Tube.	Store in dry gas compartment.	<input type="checkbox"/>	<input type="checkbox"/>
	Breath Tube.	Remove from instrument and lay on top of the when seated in the Pelican case.	<input type="checkbox"/>	<input type="checkbox"/>
Intox EC/IR II, Main Unit:		Store in the Pelican case.	<input type="checkbox"/>	<input type="checkbox"/>

Simulator:	Power Switch.	Turn off.	<input type="checkbox"/>	<input type="checkbox"/>
	Power Cable.	Remove from the hydro receptacle.	<input type="checkbox"/>	<input type="checkbox"/>
	Remove Jar.	Drain standard, rinse with water and dry with paper towel.	<input type="checkbox"/>	<input type="checkbox"/>
	Head.	Rinse with water and dry with paper towel.	<input type="checkbox"/>	<input type="checkbox"/>
	Attach jar to head.	Store in Pelican case in the insert space provided.	<input type="checkbox"/>	<input type="checkbox"/>
	Mercury Thermometer	*****Remove***** Do not ship with simulator. Store locally.	<input type="checkbox"/>	N/A
Checklist		Place checklist into Pelican case.	<input type="checkbox"/>	<input type="checkbox"/>

DO NOT SHIP DRY GAS TANK or NIST THERMOMETER

2020-05-05

V1.04